Goat.Tech

Security Review

Ethan Bennett Darklinear Solutions

Contents

About Darklinear Solutions	I
Introduction	I
Finding	I
Users can lock funds for less time than the minimum staking duration	I

About Darklinear Solutions

Darklinear Solutions leverages years of expertise in smart contract and software engineering to provide unrivaled security reviews for blockchain applications. Learn more at darklinear.com.

Introduction

Goat. Tech is a gamified protocol for determining on-chain reputation. This review consists of an issue discovered during the course of Cantina's competitive audit for the Goat. Tech in April 2024. It does not represent a full and exhaustive audit of the protocol.

The finding described below is classified according to Cantina's standards.

Finding

Unique: No other researcher identified this issue

Users can lock funds for less time than the minimum staking duration

Severity: Medium risk

Description: Despite enforcing an explicit minimum staking duration, it is possible for users to lock funds for less time than intended.

If a user locks funds in an existing position without adding to its duration, the Controller checks (in calMintStakingPower) that the lock has not expired:

```
uint rd = LLocker.restDuration(oldLockData);
// ...
if (lockTime_ == 0) {
    require(rd > 0, "already unlocked");
}
```

It then allows staking to continue without additional checks on the duration. But if rd is less than the minimum staking duration, the new funds will only be locked for that arbitrarily short period of time. In contrast, the minimum staking amount is enforced in all cases.

Recommendation: Rather than requiring that the remaining duration of the position is greater than zero, the function should check that it is greater than the minimum staking duration:

```
function calMintStakingPower(
    LLocker.SLock memory oldLockData,
    uint lockAmount_,
    uint lockTime_,
    bool isSelfStake_,
    uint selfStakeAdvantage_,
   uint minDuration_
    internal
    view
    returns(uint)
{
    uint rd = LLocker.restDuration(oldLockData);
    if (lockTime_ == 0) {
        require(
            rd > minDuration_,
            "too little time remaining"
        ); // minDuration_ = 30 days
    }
}
```